

VDO



GUIDE

DLK PRO KEY - DEFAULT SETTINGS

Step 1

Plug the Downloadkey into the PC, making sure it is switched off before doing so.

- Now open File Explorer and click on KEYTOOLS_NG. In the centre of your screen, double click on start.exe



Step 2

The program will open, for you to then click on Configuration.

- Check the settings are the same as shown below. Mass Memory download should be ticked along with Activities, Events and Faults, Technical Data and Driver Card.
- The Download period should be set to Since last download. If you have had to make changes, click on Save.

The screenshot shows the VDO software interface with the 'Configuration' window open. The window has a sidebar with icons for 'Viewer', 'Download-Reminder', 'Configuration' (highlighted), and 'Support'. The main area has tabs for 'Download configuration', 'Options', 'Password protection', and 'Inspection profile'. The 'Download configuration' tab is active, showing a 'Data blocks' section with the following settings:

- ☐ Quick Check
- ☒ Mass Memory download
 - ☒ Overview Data
 - ☒ Activities
 - Download period:
 - ☒ Since last download
 - ☐ Last
 - days: 14
 - ☐ Download period
 - From: [dropdown] to: [dropdown]
 - ☐ All activities
 - ☒ Events and Faults
 - ☐ Detailed Speed
 - ☒ Technical Data
 - ☒ Driver Card
 - ☐ Special Data

A 'Save' button is located in the bottom right corner of the configuration window.

VDO

REACH OUT FOR MORE HELP:
TIS-SUPPORT@AUMOVIO.COM
01217251312

OR

RAISE A TICKET ON MYVDO
PORTAL:



Customer Service Center

Need support? Contact our friendly VDO professionals!

> [Get support](#)



SCAN THE QR CODE

VDO